wohlenberg

Klebebinder - Perfect binder

City e - GB

B e t r i e b s a n l e i t u n g

O p e r a t i n g I n s t r u c t i o n s

Stand: 30. 7. 2004

Index

1 Technical Data 2

1.1 Plan view City "e" 2
1.2 Environmental requirements 3
1.3 Space requirement 3
1.4 Weights 4
1.5 Basic electrical data 4
1.6 Noise levels 4
1.7 Vapour extraction 5
1.8 Offcuts extraction 5
1.9 Paper 6
1.10 Adhesives 6
1.11 Perfect binding and paper 6
1.12 Binding methods 7
1.13 Formats 8
1.14 Format limitations 8
1.15 Covers 9
1.16 Cover formats 9
1.17 Cover weight 10
1.18 Air requirement for cover feeder 10
1.19 Gauze strip formats 10
1.20 Book block feeder formats 11
1.21 Book outhang 12
1.22 Groove spacing 12
1.23 Mechanical machine speed 12

2 Safety 1

2.1 Explanation of symbols and instructions 1

2.1.1 Working safety symbol 1

2.1.2 Warning instructions 1

2.2 General instructions on working safety 2

2.3 Instructions on mechanical working safety 3

2.4 Instructions on electrical working safety 4

2.5 Instructions for emergencies 5

2.6 Overview of safety devices 6

2.7 Overall view of the Emergency Off area 7

2.8 Information about personal protection and hygiene measures when handling PUR adhesives 8

3 General information 1

3.1 Introduction 1

3.2 Scope of applications 2

3.3 Copyright 2

4 Transportation 1

4.1 Packing 1

4.2 Extent of dismantling 2

4.3 Sensitiveness 2

4.4 Interim storage 2

4.5 List of items supplied 2

5 Assembly 1

5.1 General instructions - Assembly 1

5.2 Installation conditions 1

5.2.1 Dimensions, space requirement and weights 2

5.2.2 Lifting equipment 2

5.3 Setting up 2

5.3.1 Assembly 2

5.4 Preparation for putting machine into service 3

5.4.1 Mechanics 3

5.4.2 Electrics (provided by customer) 3

5.5 Reassembly 4

6 Commissioning 3

6.1 Notes - Commissioning 3

6.2 Basic Setting 3

6.2.1 Adhesive binder zero position 4
6.2.2 Basic setting for adjusting motors 5
6.2.3 Basic setting for clamp opening width 6
6.2.4 Basic setting for clamp adjustment additional pressing via cutter 7
6.2.5 Basic setting for infeed channel 8
6.2.6 Basic setting for the driver chain in the infeed channel 9
6.2.7 Basic setting for infeed station 10
6.2.7.1 Setting the infeed station parallel to the lower edge of the clamp 10
6.2.7.2 Adjusting the infeed station to the book overhang 10
6.2.7.3 Adjusting the rear guide (a) of the infeed station 11
6.2.7.4 Adjusting the front guide (b) of the infeed station 11
6.2.8 Basic setting of milling station 12
6.2.9 Basic setting of the multiple knife station 13
6.2.10 Basic setting for pressing station (1st and 2nd press) 14
6.2.10.1 Axial stroke 14
6.2.10.2 Parallelism for side pressing 15
6.2.10.3 Parallelism of pressing station relative to book spine 16
6.2.10.4 Setting the axial stroke relative to the clamp carriage 17
6.2.10.5 Adjusting the side pressing cam (only for 1st press) 18
6.2.10.6 Setting the actuator for pressing height 19
6.2.10.7 Setting the actuator for side pressing 19
6.2.11 Basic setting of cover alignment station 20
6.2.11.1 Parallelism of cover alignment station relative to book spine 20
6.2.11.2 Setting the height relative to the book spine 21
6.2.11.3 Adjustment of alignment unit to clamp carriage 21
6.2.11.4 Position indicator for Head alignment 23
6.2.12 Basic setting for the rotary cover feeder 24
6.2.12.1 Adjusting the gripper (a) to the gripper anvil (c) 24
6.2.12.2 Adjustment of the gripper pair 25
6.2.12.3 Basic adjustment of drum to the machine 26
6.2.12.4 Adjusting the pretension for the gripper 27
6.2.12.5 Control system for the stacking lever and suction shaft 28
6.2.12.6 Setting the stacking lever (Option) 29
6.2.12.7 Adjusting the suction pad height 30
6.2.12.8 Switching points of the rotary cover feeder 30
6.2.13 Basic adjustment of cover transport conveyor to alignment unit 31
6.2.14 Basic setting for cover transport 32
6.2.14.1 Parallel alignment of the cover guide 32
6.2.14.2 Basic setting for the rear cover guide 33
6.2.14.3 Basic setting for front cover guide 33
6.2.15 Basic setting for scoring station 34
6.2.15.1 Perpendicular alignment of the scoring station 34
6.2.15.2 Basic setting for rear scoring tools 35
6.2.15.3 Basic setting for the front scoring tools 36

6.2.16 Basic setting for spine gluing unit 37
6.2.16.1 Setting the height and aligning the spine gluing unit 38
6.2.16.2 Basic setting for gluing disk height and spinner 39
6.2.16.3 Setting the glue film thickness on the gluing disks 40
6.2.17 Basic setting for side gluing unit 41
6.2.17.1 Setting the height and aligning the side gluing unit 42
6.2.17.2 Basic setting for the book thickness for the rear gluing disk 43
6.2.17.3 Basic setting for book thickness for the front gluing disk 44
6.2.17.4 Basic setting for the gluing disk height 45
6.2.17.5 Setting the glue film thickness on the gluing disks 46
6.2.18 Basic setting for plate chain 47
6.2.18.1 Basic setting for short plate chain 47
6.2.18.2 Basic setting for long plate chain 48
6.2.19 Basic setting for delivery 49
6.2.19.1 Switching points for the delivery 49
6.2.20 Initial starting of the central lubrication system (Option) 50
6.2.20.1 Starting the help program 50
6.2.20.2 Venting the lines 51
6.2.20.3 Routing oil to the objects to be lubricated 51
6.2.21 Basic adjustment of the gauze station 52
6.2.21.1 Adjusting the gauze station parallel to the book spine 52
6.2.21.2 Basic adjustment of cutter motion 53
6.2.21.3 Basic adjustment of gauze feed 53
6.2.21.4 Basic adjustment and alteration of book hang-out 53
6.2.22 Calling up the factory settings 54
6.3 Mechanical Trial Run with Material 54

7 Operation 2

7.1 Production Mask 2
7.1.1 Fault messages in the production module 3
7.1.2 Input in the operator masks 3
7.2 Operating Modes 4
7.2.1 Jogging mode 4
7.2.2 Solo mode 4
7.2.3 Combined operation 4
7.2.4 Backwards jogging mode 5
7.2.5 Night mode 5
7.2.6 Day mode 5
7.3 Setting Up the Machine 7
7.3.1 Retrieving settings from the database 8
7.3.2 Opening the setup mask 10
7.3.3 Manual adjustment 12
7.3.3.1 Setting the roller transfer to the book thickness 12
7.3.3.2 Setting the height monitor in the infeed channel (Option) 13
7.3.3.3 Setting the thickness monitor in the infeed channel (Option) 13
7.3.3.4 Setting the round bar guides in the transport channel 13
7.3.3.5 Infeed station 14
7.3.3.6 Roughening- or Notching depth 14
7.3.3.7 Hotmelt - Spine gluing unit 15

7.3.3.8 PUR - Spine gluing unit ... 16
7.3.3.8.1 Refilling the PUR – Gluing unit 17
7.3.3.8.2 Change pot 17
7.3.3.8.3 Emptying the PUR gluing unit 18
7.3.3.9 Side gluing unit ... 19
7.3.3.10 Adjust Heating unit ... 20
7.3.3.11 Cover feeder ... 21
7.3.3.12 Adjusting scoring depth ... 21
7.3.3.13 Adjusting the cover aligning station ... 22
7.3.3.14 Additional pressing strips for 1st and 2nd pressing station ... 23
7.3.3.15 Adjusting the gauze station ... 24
7.3.3.15.1 Adjusting the gauze station to the clamp carriage 25
7.3.3.15.2 Guidance of back binding material 25
7.3.3.15.3 Threading the back binding material 26
7.3.3.15.4 Strip length 26
7.3.3.15.5 Strip width / feed 26
7.3.3.15.6 Adjusting the stop on the feed table 27
7.3.3.15.7 Adjusting the side overhang in relation to book block 27
7.3.4 Correcting products ... 28
7.3.4.1 Overview of correction masks ... 29
7.3.5 Manual corrections ... 30
7.3.5.1 Spine gluing unit ... 30
7.3.5.2 Side gluing unit ... 30
7.3.5.3 Cover transport ... 31
7.3.5.4 Scoring station ... 31
7.3.5.5 Gauze station ... 31
7.3.5.6 Adjusting the side pressing cam ... 32
7.3.5.7 Plate chain ... 32
7.4 Types of Products ... 33
7.4.1 Fabrication of brochures ... 33
7.5 Starting the Machine ... 34
7.6 Service Module: ... 35
7.7 System Module ... 36
7.8 Traffic Light – Color Indicator ... 37

8 Faults - Consequences and Elimination ... 2

8.1 Fault Messages ... 2
8.1.1 Diagnosis ... 2
8.1.2 Fault list (History) ... 3
8.1.3 Service submenu ... 4
8.2 Defects to the product ... 5
8.2.1 Hollow cover at the spine ... 5
8.2.2 One-sided scoring ... 6
8.2.3 Glue between layers (glue penetration) ... 6
8.2.4 Round book spines ... 7
8.2.5 Imprinted book spine - (nail head) ... 7
8.2.6 Outer layers projecting - (layer fault) ... 7
8.2.7 Round book spine at head ... 8
8.2.8 Page edges breaking free in hotmelt binding Hotmeltbindung ... 8

9 Maintenance 3

9.1 Notes - Maintenance 3
9.2 Maintenance intervals 4
9.2.1 Maintenance before start of production (daily) 4
9.2.2 Maintenance, monthly 4
9.2.3 Maintenance, 6-monthly 5
9.3 Summary of lubricants 6
9.4 Central lubrication system (Option) 7
9.5 Inspection 8
9.5.1 Maintenance of clamp carriage 8
9.5.2 Changing the clamp carriage 10
9.5.3 Maintenance of clamp guide 12
9.5.4 Maintenance of the spine gluing unit (hotmelt) 13
9.5.5 Maintenance of the spine gluing unit (PUR 14
9.5.6 Maintenance of the side gluing unit (hotmelt) 15
9.5.7 Cleaning the side gluing unit (cold glue 16
9.5.8 Maintenance of the premelters of the spine and side gluing units 17
9.5.9 Maintenance notes for roller chain drives 18
9.5.10 Tensioning the clamp carriage chain 19
9.5.11 Replacing the milling knife and counter blade block 20
9.5.12 Replacing the three-blade knife multiple knife head 22
9.5.13 Adjusting the safety coupling of the main drive 24
9.5.14 Adjusting the safety coupling of the transfer chain 25
9.5.15 Adjusting the safety coupling of the plate chain 26
9.5.16 Replacing the gauze knife 27
9.6 Cleaning the Machine 29
9.7 Replacing the UGV storage batteries 30

10 Spare parts stock and customer service 1

10.1 Spare parts stockists 1
10.2 Ordering spare parts 2
10.3 Addresses for spare parts and customer services 3
10.4 Deutschland / Germany 4
10.5 Europe / Europa 6
10.6 Africa / Afrika 10
10.7 North America / Nordamerika 14
10.8 Middle America / Mittelamerika 14
10.9 South America / Südamerika 16
10.10 Asia / Asien 17
10.11 Australia and Ocean Side / Australien und Ozeanien 22

11 Electrical documentation 1

11.1 Notes – electrical documentation 1
11.2 Control panels on the Perfect binder 2
11.2.1 Overview of control panels on the Perfect binder 2
11.2.2 Main control panel 3
11.2.3 Control panel of machine infeed section 4
11.2.4 Control panel of spine gluing unit PUR 4
11.2.5 Control panel of cover feeder 5
11.2.6 Operator panel - Control cabinet 6
11.2.7 Operator panel - Machine delivery section 6
11.2.8 Operator panel – Gauzing station 7
11.2.9 Control panel of infeed conveyor 7
11.2.10 Control panel of PUR-gluing unit 8
11.3 Navigator 8
11.4 Basic electrical data 9
11.5 Electrical spare parts list 9
11.6 Circuit diagrams 9

12 Appendix 1

12.1 Bagging device 2
12.2 Vapour extraction 3
12.2.1 Pump Ranges 4
12.2.2 Description 4
12.2.3 Suitabillty 4
12.2.4 Handling and Setting up (pictures 1 to 5) 5
12.2.5 Installation (pictures 1 to 5) 6
12.2.6 Initial Operation (pietures 4 and 5) 6
12.2.7 Adjusting the capacity of RER/REL 7
12.2.8 Potential risks for operating personnel 8
12.2.9 Maintenance and Servicing 8
12.2.10 Trouble Shooting: 8
12.2.11 Appendix: 9
12.2.12 Spare part lists 10
12.3 Pressure / Vacuum pump 12
12.3.1 Pictures 1 and 2 12
12.3.2 Pump Ranges 13
12.3.3 Description 13
12.3.4 Picture 3 13
12.3.5 Sultability 14
12.3.6 Handling and Setting up (pictures 1 to 4) 14
12.3.7 Installation (pictures 1 to 3) 14
12.3.8 Initial Operation (pictures 1 to 3) 15

12.3.9 Potential risks for operating personnel 15
12.3.10 Pictures 4 and 5 16
12.3.11 Maintenance and Servicing 16
12.3.12 Picture 6 17
12.3.13 Trouble Shooting 18
12.3.14 Appendix: 19
12.3.15 Spare parts list 20
12.4 Cold gluing pump 22
12.4.1 Installation and operation 23
12.4.2 Additional information on the various pump types 24
12.4.2.1 Pumps with housings of electrical conductive plastic (option code K) 24
12.4.2.2 ALMATEC COMPACT (AC series) 24
12.4.2.3 ALMATEC High-Pressure Diaphragm Pump (AH series) 24
12.4.2.4 ALMATEC Pulsation Damper (APIAT series) 24
12.4.3 Spare parts list 25
12.6 PLC 25

FOR FULL MANUAL ACCESS CONTACT
PARTS DEPARTMENT
Mike Keller
800-236-7603 ext. 1010
SUBMIT REQUEST ONLINE

BEST GRAPHICS ARCHIVES

BEST GRAPHICS GROUP

BEST GRAPHICS
FULL SPECTRUM PRINT | PACKAGING | DIGITAL
CALL FOR DETAILS | 800-236-7603 | bestgraphics.net