

IBIS Smart-binder Operator's Manual

For SB1, SB2, SB3 and SBX



Preface

IBIS Integrated Bindery Systems Ltd, is specifically not liable for any damage or injury arising from failure to follow the instructions contained in this manual, or failure to exercise due care in the installation, operation, and servicing of this equipment.

This manual applies to Smartbinders running Version 7 software.

Spare Parts and Service:

For spare parts and service enquiries, please contact:

IBIS Integrated Bindery Systems Ltd Cressex Business Park High Wycombe Buckinghamshire UK HP12 3SU

+44(0)1494 561950

Email: service@ibis-bindery.com

Revision History

Revision	Date	Description of Change	ECR No
00		First Issued	

Contents

Using the	e Smart-binder	6
2.1 Ope	rating the Smart-binder	6
2.1.1		
2.1.2		
2.2 Con		
_		
	•	
	·	
	•	
	·	
	·	
_		
	ding	33
	· · · · · · · · · · · · · · · · · · ·	
4.2 Mak		
4.2.1	Adjust the position and angle of the infeed registration guide	38
4.2.2	Place the Infeed Conveyor Balls	38
4.2.3	Adjust the sheet and cover Scoring pressure	39
4.2.4	Adjusting the hold down fingers	39
4.3 Fau	It Messages	40
4.4 War	ning Messages (grey)	44
4.5 War	ning messages that require operator intervention (blue)	44
6.1.2		
-		
-		
	· · · · · · · · · · · · · · · · · · ·	46
	Using the 2.1 Ope 2.1.1 2.1.2 2.2 Con 2.2.1 2.2.2 2.3 Adju 2.3.1 2.3.2 2.3.3 2.3.4 2.3.5 2.3.6 2.3.7 2.3.8 2.3.9 2.4 Ente 2.4.1 2.4.2 2.4.3 2.4.4 2.4.5 2.4.6 Other ful 3.1 Disp 3.2 Character ful 3.1 Disp 3.2 Character ful 4.1 Boo 4.2 Mak 4.2.1 4.2.2 4.2.3 4.2.4 4.3 Fault Fin 4.1 Boo 4.2 Mak 4.2.1 4.2.2 4.2.3 4.2.4 4.3 Fault Fin 4.1 Boo 4.2 Mak 4.2.1 4.2.2 4.2.3 4.2.4 4.3 Fault Fin 4.1 Boo 4.2 Mainten 6.1 Mainten 6.1 Mainten 6.1 Mainten 6.1.1 6.1.2 6.2 Main 6.2.1 6.2.2 6.2.3	Using the Smart-binder 2.1 Operating the Smart-binder. 2.1.1 Turning on 2.1.2 Turning off. 2.2 Control Panel Functions 2.2.1 Operator's pushbuttons 2.2.2 The Main Menu 2.3 Adjust the Smart-binder for a new job 2.3.1 Load an existing setup 2.3.2 Adjust the Infeed and Collator for a different sheet size 2.3.3 Adjust the Infeed and Collator for a different sheet size 2.3.4 Adjust the Push out conveyor so that the book is centred in the trimmer. 2.3.5 Adjust the Stitches for book thickness 2.3.6 Adjust the Stitches for book thickness. 2.3.7 Adjust the Backstops for the size of book 2.3.9 Adjust the Trimmer Side Joggers 2.4 Enter new setup parameters 2.4.1 Loading, saving and deleting setups. 2.4.2 Setup – Sheets 2.4.3 Setup – Barcodes 2.4.4 Setup – Books 2.4.5 Setup - Gluing 2.4.6 Setup - Perforator Other functions 3.1 Display information about the operation of the Smart-binder 3.2 Changing machine operating modes. 3.2.1 Makeready options. Fault Finding. 4.1 Book Quality 4.2 Making fine adjustments. 4.2.1 Adjust the position and angle of the infeed registration guide. 4.2.2 Place the Infeed Conveyor Balls 4.2.3 Adjust the sheet and cover Scoring pressure 4.4.4 Warning Messages (grey) 4.5 Warning messages (grey) 4.6 Warning messages (grey) 4.7 Warning messages that require operator intervention (blue) Maintenance 6.1 Maintenance Intervals 6.1.1 Every 16 hours of running 6.2 Maintenance operations 6.2.1 Cleaning belts and rollers 6.2.2 Cleaning clincher area.

1 Safety

- ♦ Press-in the Emergency Stop Button during maintenance or while making adjustments.

The Guards shown opposite are installed to protect you from moving parts that are potentially hazardous. Never remove or change any of the guards.

- Never override any of the machine interlocks
- Observe all Warnings and Cautions, they are there for your safety.

WARNING


A Warning is placed before any procedure that if not followed could result in personal injury.

CAUTION

A Caution is placed before any procedure that if not followed could result in damage to the equipment.

- **Ensure that the floor around the machine is kept clear of all obstacles.**
- Wear clothes in a manner that eliminates the possibility of being snagged by the machine.
- This equipment must be installed, adjusted and serviced by qualified personnel, who have been trained in its commissioning, service and operation.

M0009305 rev 00



- A Scoring area, end fixed guard
- B Scoring area, rear fixed guard
- C Scoring area, rear fixed guard
- D Scoring area, rear fixed guard
- E Scoring area front fixed guard
- F Scoring area guard
- G Stitcher guard
- H Stitcher rear fixed guard
- Stitcher front fixed guard

- I Trimmer fived quard
- K Trimmer side guard
- I Trimmer fixed quard
- M Trimmer fixed quard
- N Reject guard
- Trimmer fixed quarc
- P Trimmer fixed guard
 - Trimmer guard

FOR FULL MANUAL ACCESS CONTACT PARTS DEPARTMENT

Mike Keller

800-236-7603 ext. 1010 **SUBMIT REQUEST ONLINE**





BEST GRAPHICS
FULL SPECTRUM PRINT | PACKAGING | DIGITAL